


STEP 3: Secure display sign onto the POP display with the velcro. See *Figure 3*.



Figure 3



POP Instruction Manual




For further questions and/or assistance, please contact our Customer Support team via text/call at 801.820.7020 or via email at sport@weigh-safe.com.

www.weigh-safe.com

PARTS

PART	QTY
Long Legs	2
Short Legs	2
Lower Post	1
Upper Post	1
Screws	6
Velcro Display Sign	1



STEPS

STEP 1: Begin by inserting all 4 legs (both short and long legs) into the bottom portion of the bottom post and secure each leg with a screw until tight. See *Figure 1*.




Figure 1

STEP 2: Place the upper post over the lower post and secure with (2) screws until tight. See *Figure 2*.




Figure 2