WHEEL LEVELING SET



INSTRUCTIONS

STEP 1

Set Rubber Mat & Wheel Leveler under the tire as shown. Push Wheel Leveler as far as it can go.



STEP 2

Slowly drive onto Wheel Leveler until vehicle is level.



STEP 3

Wedge smaller Wheel Chock under Wheel Leveler as shown.



STEP 4

Put vehicle in neutral to let the wheel settle.



NOTE:

For dual axle trailers with limited space (less then 2") between tires, a maximum of 4" can be cut off the end of the Wheel Leveler.



INSTRUCTIONAL VIDEO





FAILURE TO FOLLOW THESE WARNINGS COULD CAUSE UNSTABLE CONDITIONS. IMPROPER USE MAY RESULT IN PROPERTY DAMAGE, INJURY OR DEATH.

- ALWAYS inspect each component for damage prior to use. **DO NOT** use if damaged.
- **ALWAYS** align Wheel Levelers with centerline of tires. Failure to do so can lead to instability.
- **ALWAYS** put the vehicle in park and engage the parking brake.
- ALWAYS keep hands, feet and other objects clear during leveling process.
- **ALWAYS** ensure components are dry to prevent slipping during leveling.
- **NEVER** stack additional items on top of or below of Wheel Leveling components for additional height.
- **NEVER** exceed weight rating capacity.
- **ONLY** use the Wheel Leveling Set for it's intended use.



QUESTIONS OR CONCERNS?

Contact our Customer Support team!

Call or text us at **801.820.7020**Email us at **customersupport@weigh-safe.com**