

# **CERAKOTE BLACK 180 DROP HITCH INSTRUCTION SHEET**



## **STEP 1**

ENSURE THE 180 HITCH BALL PIN (A) IS INSERTED FULLY INTO THE 180 SLIDER (B). THIS PIN SHOULD BE ENGAGED AND GENERALLY ISN'T SUPPOSED TO BE REMOVED. DO NOT OPERATE WITHOUT 180 HITCH BALL PIN (A) IN PLACE.



## **STEP 2**

PLACE THE 180 SLIDER (B) AT THE DESIRED DROP ON THE DRAW BAR (C) TO ENSURE THAT YOUR VEHICLE AND TRAILER ARE PROPERLY POSITIONED.



#### **STEP 3**

ONCE YOU HAVE ACHIEVED THE DESIRED POSITION ALONG THE DRAW BAR (C), INSERT THE DUAL PIN KEY LOCK ASSEMBLY (D) INTO THE 180 SLIDER (B) AND LOCK IN PLACE BY TURNING THE KEY.



### STEP 4

PULL ON THE DUAL PIN KEY LOCK ASSEMBLY (D) TO ENSURE THAT THE LOCK HAS SECURELY ENGAGED AND PLACE THE DUST LOCK COVER (E) OVER THE LOCK. DO NOT OPERATE WITHOUT MAKING SURE THE KEY LOCK ASSEMBLY (D) IS SECURELY LOCKED IN PLACE.



#### PORTANT SAFETY INFORMATION

Ensure safety chains are attached between vehicle and trailer. DO NOT attach chains directly to hitch. Never exceed the LOWER rating between: A) Tow vehicle manufacturer's load OR B) Weigh Safe Hitch GTW hitch ratings: 7,500 lbs. (1-7/8" ball), 8,000 lbs. (2" ball), 12,500 lbs. (2-5/16" ball & 2" shank), 18,500 lbs. (2-5/16" ball & 2.5" shank), 21,000 lbs. (2-5/16" ball & 3" shank). Tongue Weight should be between 10-15 % of gross trailer weight. Weigh Safe Hitch max tongue weight is 1,500 lbs. (2" shank) and 2,200 lbs. (2.5" & 3" shanks). Secure your Weigh Safe Hitch to a standard 2", 2.5" or 3" receiver with locking pin.

